Model THE0151BT



AGTEC PORTABLE REFRACTOMETER WITH COPPER ATC (0-32 BRIX)

FEATURES:

- Copper construction
- · Adjustable eyepiece
- · Heavy duty analog design
- Measuring range: 0-32% Brix
- Accuracy: +/-0.20% Brix
- Compensation temperature range: 10°C-30°C (50°F-86°F)
- Calibration: zero calibration with water at 20°C (68°F)
- Measures in .2 Brix increments
- · Comes in a durable, foam-padded carrying case
- 1 year warranty

This heavy duty analog refractometer provides accurate, consistent measurements on an easy to read scale. It tests the amount of sugars and dissolved solids in fruits, vegetables, grasses and liquids with as little as 2 drops of solution.

This meter can also be used in wine and beer making to measure and monitor sugar levels as a beverage ferments. The built-in automatic temperature compensation from 0 to 30°C (50°F-86°F) prevents brix readings from becoming skewed by common temperature variations.